# VCM36-W

# Introduction

The Yealink VCM36-W is an innovative wireless video conferencing microphone designed to accommodate various meeting room needs. With a built-in 3-microphone array, the VCM36-W has a 20ft (6m) and 360° voice pickup range. It features Yealink's high-quality echo cancellation technology and noise cancellation, effectively filtering out up to 90dB of ambient noise to provide a high-quality audio experience during full-duplex calls. The VCM36-W's high-quality pickup technology provides a full range of audio coverage for all conference room sizes.

The VCM36-W is easy to use with a single pairing, with up to 12 hours of battery life in conference mode and 7 days of standby time. The VCM36-W WIFI microphone is equipped with a charging dock that allows you to charge the microphone wirelessly, and you can change its deployment position at any time while using it to suit your needs.





6 m and 360°

voice pickup range

HD Hi-Fi Wifi Microphone

Yealink Full Duplex Technology



12 hours battery life of conference

WPA2, AES128 Encryption Technology



## **Key features and benefits**

- HD Hi-Fi Wifi Microphone
- Yealink Full Duplex Technology
- Dual-band 2.4GHz/5GHz wireless networks
- 6m-360° voice pickup range
- 12 hours battery life of conference
- WPA2, AES128 Encryption Technology

## **Specifications**

Specifications	Description
----------------	-------------

Microphone Features	<ul> <li>Optimal HD Audio</li> <li>Yealink Full Duplex Technology</li> <li>Yealink Acoustic Echo Canceling</li> <li>Yealink Noise Proof Technology</li> <li>6 m voice pickup range</li> <li>Muting the microphone with touchpad</li> <li>Can be used as an expansion microphone</li> <li>Built-in 2450 mAh battery</li> <li>Up to 12 hours of use time</li> <li>Up to 7 days standby time</li> <li>Frequency response: 100Hz to 8kHz</li> </ul>	
Wi-Fi	<ul> <li>Standard: 802.11 b/g/n/ac</li> <li>Frequency: 2.4GHz/5GHz</li> <li>Security: WPA-PSK/WPA2-PSK</li> </ul>	
Physical Features	<ul> <li>Dimension (W DH):</li> <li>Microphone: 100 x 16.5 mm</li> <li>Charge Cradle: 100 x 10.5 mm</li> <li>Operating humidity: 10% - 90%</li> <li>Storage temperature: 0°C - 40°C (+32°F - 104°F)</li> </ul>	
Package Contents	<ul> <li>1x VCM36-W Video Conference Microphone</li> <li>1x Charger Cradle</li> <li>1x 1.2 m USB-C Cable</li> <li>1x USB Adapter (not included for Thailand market)</li> <li>Double-sided adhesive</li> <li>Quick Start Guide</li> </ul>	
Package Features	<ul> <li>Qty/CTN: 20 PCS</li> <li>N.W/CTN: 8.068 kg</li> <li>G.W/CTN: 8.678 kg</li> <li>Giftbox size: 184 x 112 x 60 mm</li> <li>Carton Meas: 635 x *237 x 200 mm</li> </ul>	

# **Device Compatibility**

The maximum number of VCM36-W microphones supported by the conferencing room endpoint is as follows:

## $\textbf{i)} \, \textbf{NOTE}$

- Since the microphones do not support mixed-use, the kits with this microphone or MSpeech do not support other microphones by default. For which kits contain microphones or MSpeech, please refer to datasheet.
- The MVC840-BASE KIT/MVC860-BASE KIT refers to kits without the VCM34 microphone.

Device Name	Max. number of VCM36-W supported
MeetingBar A10	×

# Yealink

MeetingBar A20	1 (A20 version requires 133.320.0.2 and later)
MeetingBar A30	2 (A30 version requires 133.320.0.2 and later)
MVC960, MVC940, MVC900	×
MVC860, MVC840, MVC660, MVC640-AI	×
MVC860-BASE KIT, MVC840-BASE KIT, MVC640- Wireless, ZVC860, ZVC840	4 (UVC86 version requires 151.431.0.5 and later, UVC84 version requires 262.431.0.5 and later)
MVC400, ZVC400	×
MVC320	×
MeetingBoard 65, MeetingBoard 86	2 (MeetingBoard 65&86 version requires 155.15.0.46 and later)
DeskVision A24	×
MeetingEye 500	2

## How to Use

VCM36-W has different features when used with different video conferencing endpoints. For more information, please refer to the corresponding documents.

### **Teams Verison**:

- Connect the VCM36-W to MeetingBar A20/A30: VCM36-W Wireless Microphone
- Connect the VCM36-W to MVC System: VCM36-W Wireless Microphone
- Connect the VCM36-W to MeetingBoard 65/86: VCM36-W Wireless Microphone

#### Zoom Version:

- Connect the VCM36-W to MeetingBar A20/A30: VCM36-W Wireless Microphone
- Connect the VCM36-W to ZVC System: VCM36-W Wireless Microphone
- Connect the VCM36-W to MeetingBoard 65/86: VCM36-W Wireless Microphone
- Connect the VCM36-W to MeetingEye 500: VCM36-W Wireless Microphone

#### **BlueJeans Version**:

• Connect the VCM36-W to MeetingBar A20/A30: VCM36-W Wireless Microphone

#### **RingCentral Version**:

• Connect the VCM36-W to MeetingBar A20/A30: VCM36-W Wireless Microphone

## **LED Indicator**

#### **Charging LED Indicator:**


LED Indicator Status	Description
Solid red	Charging
Solid green	The VCM36-W is fully charged
Flash red slowly	Low battery(lower than 20%), and please charge

Flash red 3 times and then off	The battery is too low to power on
Solid green for 3 seconds and then off	Standby
Solid green for one second and then off	Power on
Off	If you tap the mute button and the Charge indicator LED on the VCM36-W is still off, it means the VCM36-W is powered off

# Mute LED Indicator:


LED Indicator Status	Description
Solid red	The system is muted
Solid green	The system can pick voice
Slowly flashing yellow	The VCM36-W is searching for signal
Off	The system is in the idle state

# Hardware Introduction



Charge

# Yealink



## **Power On and Off**

1. Press and hold the **Mute** button for 5 seconds.

The charging LED indicator turns green and then turns off during startup.

2. Press and hold the **Mute** button for 15 seconds.

The charging LED indicator turns red and then turns off. If the device does not respond after pressing the **Mute** button, it is powered off.

## **Mute/Unmute Microphone**

- 1. Press the **Mute** button on the VCM36-W to mute the microphone. If the muting LED indicator is solid red, the microphone is mute.
- 2. Press the **Mute** button again to unmute the microphone.