

# Dell Active Pen

## PN350M

### Quick Start Guide

Guía de usuario rápida


Guia rápido do usuário

퀵 스타트 가이드

Краткое руководство

Schn`ellstart anleitung


快速入門手冊




1



2



3



Regulatory Model: SPEN-DEL-01

[Dell.com/PN350M](http://Dell.com/PN350M)



[Dell.com/support/manuals](http://Dell.com/support/manuals)

[Dell.com/regulatory\\_compliance](http://Dell.com/regulatory_compliance)





## Draw

Dibujar | Desenhar | 그리기  
Рисование | zeichnen | 繪圖





## Menu

Menú | Menu | 메뉴  
Меню | Menü | 選單



## Select

Seleccionar | Seleccionar | 선택  
Пометить | wählen | 選擇



## Erase

Borrar | Apagar | 지우기  
Удалить | Löschen | 抹除

