

INSTALLATION INSTRUCTIONS

Product

7160-1473

ZEBRA ZQ620 PRINTER MOUNT

Revision

<u>n Form</u>

Rev A INST-954

Printing Spec: PS-001

This instruction sheet is for the 7160-1473 printer mount only. For information on the Zebra ZQ620 printer see the manual supplied with the printer.

Attaching the printer mount to the printer:

- 1. With the printer positioned upside down, place the mounting bracket on the bottom and slide the hooks into the openings on the front side.
- 2. With the bracket in place, install the (2) #4-40 x 1/4" long machine screws provided in hardware bag 7120-0943.



#4-40 x 1/4"machine screws



printer mounting bracket

Attaching to a motion attachment:

- The printer (with mounting bracket attached) can now be mounted to a motion attachment like a 7160-1261 or other type of motion attchment with the AMPs hole pattern.
- 2. Attach the printer mount to the motion attchment with the (4) #10-32 lock nuts provided in hardware bag 7120-0943.





Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brake lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

7160-1261

© Copyright 2019 Gamber-Johnson, LLC