



Universal CPU Holder




Overall dimensions vary based on the CPU dimensions

Top Bracket Dimensions



Bottom Bracket Dimensions



© 2006 Ergotron, Inc. rev. 10/10/2006 DIM-CPU Content is subject to change without notification.

Americas Sales and Corporate Headquarters

St. Paul, MN USA
(800) 888-8458
+1-651-681-7600
www.ergotron.com
sales@ergotron.com

EMEA Sales

Amersfoort, The Netherlands
+31 33 45 45 600
www.ergotron.com
info.eu@ergotron.com

APAC Sales

Singapore
www.ergotron.com
info.apac@ergotron.com

Worldwide OEM Sales

www.ergotron.com
info.oem@ergotron.com

