




5. WIRED SETUP




6. SD-CARD PLAYBACK



7. PHONE CALL




FAQ




USER GUIDE
SOUNDBAR SPEAKER

1. CHARGE SPEAKER



2. WIRELESS SETUP 1/2



3. WIRELESS SETUP 2/2



WIRELESS TROUBLESHOOTING



4. WIRELESS PLAYBACK

